

Fitting instructions

Weather Stop Roller Shutter Door Wrap-Around Seal Kit

The Wrap-Around Thermoplastic Bottom Seal, fits all standard 75mm T-bar bottom sections of commercial roller doors. It is very quick and easy to fit with no fixings/ sealant is required.

Tools Required

- Tape measure
- A pair of sharp scissors/ stanley knife
- Pencil

It is important to follow instructions carefully.

(Must be fitted a person over the age of 18)
Work is undertaken at the purchaser's own risk. Due care and attention should be paid when stepping over the Weather Stop floor seal at all times.

Step One



With a tape measure, measure the bottom of the roller doors

Step Two



Mark with a pencil the exact length of thermoplastic seal that needs to be cut in order to fit the opening. Use scissors to cut the door seal to size.

Step Three



With the garage door half open and working from one end, press and clip on one side of the flap. Repeat this process along the length of the seal. (USEFUL TIP Another person holding the other end of the seal will make the task much easier!)

Step Four



Working from one end pull the other flap back and pull it over the T-bar bottom sections on the roller door. Repeat this process all the way along until the seal is fully connected on the T-bar.

Step Five

Close the Roller Shutter and make sure the door shuts and is locking correctly.

Note: Due to coiling, there may be a 'ripple' effect along the bottom of the seal. Please allow a few days with product in situ and it will return to its original extruded shape.

